

## LinHES - Support # 1020: Missing IR USB-UIRT transmitter and I would to add a TELUS transmitter codes

<b>Status:</b>	Rejected	<b>Priority:</b>	Normal
<b>Author:</b>	paulpoco	<b>Category:</b>	Installation/Upgrade
<b>Created:</b>	11/05/2017	<b>Assignee:</b>	jams
<b>Updated:</b>	11/06/2017	<b>Due date:</b>	
<b>Description:</b>	<p>I am new to linHES.</p> <p>Had a previous system that had a working MythTV/Kodi using the USB-UIRT transmitter to change the channels of a TELUS stb.</p> <p>USB-UIRT is missing from remotes. Of I cannot find my old setup for this.</p> <p>TELUS is not in the list of boxes for transmitting. My uploaded file is general.conf.</p>		

### History

11/06/2017 03:21 pm - brfransen

- Status changed from New to Rejected